

Rubdowns (Anreibefolien)

Application instructions



Position



Rubdown



Remove carrier film



Applied rubdown

Rubdown tool

To rubdown use a metallic rubdown tool (available @ identico) or a wooden tool.

Optimal surface

Make sure the surface is clean and fat free, clean with a surface cleaner (without oils). **Important:** Test in a hidden place.

If painted surface, use gloss paint or varnish, and ensure it's completely dry.

Application

- Cut out the desired subject. Position the Rubdown, with the backpaper, exactly on the surface. Use duct tape to keep in position
- **Important:** The rubdown should not slip on the surface after remove the backpaper
- Take away the backpaper and press with your finger the rubdown on the surface, to keep it in place
- Rubdown with a gentle pressure
- Remove the carrier film by fold 180°, remove carefully
- If needed take the backpaper (with the printed side to you) press it on the applied rubdown to fix

Clean glue residues

To clean some glue residues, wet a soft cloth soaked by surface cleaner, drive over carefully

Varnish finish

Spray varnish gloss/matt after drying at least 24 hours, to protect. (testing recommended!)

Store in a cool and dry place.

Identico & Partner AG
Glatttalstrasse 63, CH-8052 Zürich
Telefon +41 (0)44 315 65 75
info@identico.ch • identico.ch